

LED FRESNEL LIGHT WITH ZOOM

MJ-3331C200-2IN1



User Manual

=====PROFESSIONAL LED LIGHTING =====

Thank you for choosing our LED fresnel light. For the sake of your safety, Please read and follow these instructions carefully and keep this manual in a safe place for future reference.

APPENDIX

Problem	Reason	Resolution
Device not work	No power	AC100V-250V,50HZ/60HZ Check the power connection, and make sure device connect the mains in well condition. Check if switch is on Check if the fuse is good
		led bulb damaged
Led bulb is off	Led driver board damaged	Replacing led driver board
	temperature swtich damaged	Replacing temperature switch
Fans not work	Fans damaged	replacing fans

Caution :

* Unqualified person involved with installation , operation and maintenance of this device is prohibited .

* If any above mentioned problem happened , or unknown problem happened , please contact manufacturer or distributor for assistance

DISCLAIMER

1. The device is with one year warranty . The warranty period appear non-artificial quality problem, this company is responsible for free maintenance
2. User violate operation caused the machine failure, this is user responsibility.
3. If due to the wrong operation or intense impact caused product destroy even safety accidents, the manufacturer does not undertake any responsibility
4. Prohibit replaced product components by any person, therefore caused any consequences will be whose responsible

Please contact us freely when you need our related products or in formations...

OVERVIEW

Thank you for using our product, this unit is designed for indoor using, it's widely used for stage, building, disco, etc. as high power led effects lighting, this unit can be operated as a single unit or multiple units for large applications. Direct input of DMX512 signal to unit to allow it controlled by any DMX controller, powerful internal programs and friendly and convenient operation interface allows customers to program freely to any different lighting project requirements for installation or showing.

This high power profile spot light has gotten the nice sculpt, efficient, save electricity and durable .

Technical Parameter:

- Power Supply: AC100V-240V, 50/60Hz
- Power Consumption: Max. 260W
- LED: 200W 2in1 Cool white and Warm White Color
- LED Life time: Over 50,000 hours
- Small volume, lightweight
- High quality optical system
- Beam Angel: 15-50°
- Features: With zoom by manual
- High-quality optical system , Glass reflector
- Control Mode: DMX, Auto run and Master/Slave
- DMX Channels: 2/ 5CH
- Housing: Plastic Color: Black
- IP Rating: IP20
- Warranty : One year
- N.W.:8.5 kgs
- G.W.: 10kgs
- Dimensions :580x325x320mm

1. Product Introduction

1.1 Product Feature

- **2 kinds of running model**
 - External control mode (Slave model)
 - ◆ DMX 512 controller control(2 kinds channel modes)
 - ◆ Master/salve model control (auto match the signal from controller and the Master light, no need to set by menu)
 - static mode (Master model)
 - ◆ It can fix any color without the controller ,also work this color with strobe
- **Non-linear dimmer and linear dimmer**
 - The speed of dimmer can be set under the controller control
- **Screen Protect**
 - It will enter blank screen without any operate on the keyboard in 30 seconds . Press any keys then it can quit screen protection.
- **Temperature Protection**
 - It can be set to temperature protection mode
- **Speed of the Fan**
 - The fan will start to work when the working temperature reach 40 degree, and the speed will be changed according to the change of temperature.
- **Can be Reverse display**

1.2 Multi-light working in the same time

When using controller to control multi lights to work in strobe, the controller just send the channel data . The strobe effect will be depend on each light itself . And please take attention for the follow situation:

1. There will be many situations make the lights are not synchronization in the beginning. (For example: the different time of opening the light , or different time of them connect to the controller) .In this case, you can change value of the controller(for example push 20 to 0, and back to 20), then it can be synchronization.
2. Due to crystal frequency of different lights are not the same exactly, so it may not be synchronization after long time.

SAFETY WARNING

1. Warning

- * Every person involved with the installation , operation and maintenance of this device has to be qualified .
- * User must follow the instructions of this manual
- * Unqualified person can not open the housing cover and operate the device , or the dealer will not accept liability for any resulting defects or problems.
- * The device against rain and moisture

2. Waring notes :

- * Power supply : AC 100V-240V , 50/60Hz
- * Make sure the power switch is off , the power plug , outlet and the earth connection is in well condition before connecting the device with the mains.
- * Please use qualified power plug and the outlet. Never connect the power cord of this device with other electrical equipment.
- * During move and installation , make sure the device not crashed with metal parts and other tough materials.
- * Always disconnect from the mains, when the device is on the installation and dismantled
- * The minimum distance between light-output and the illuminated surface must be more than 50cm
- * The device must only be installed on a non-flammable surface . In order to safeguard sufficient ventilation , leave 50cm of free space around the device . Please note that heat-sensitive objects may be deformed or damaged by the emitted heat .
- * During the operation the housing becomes very hot ! Do not operate the device for 15 minutes after switching off .
- * The maximum ambient temperature $T_a = 45^{\circ}\text{C}$ must never be exceeded , The maximum housing temperature $T_b = 80^{\circ}\text{C}$ must never be exceeded .
- * For indoor use
- * Replace any visible cracked protective shield , filters and lens .
- * The protective shiel, filters and lens will require weekly cleaning as smoke “Cfluid tends to building up residues , reducing the light “Coutput very quickly.

	two vice menu	tEMp: temperature	ENTER	enter the vice menu	
		temperature control			
		current temperature	ENTER	change to vice menu	
	t: top	UP/DOWN	change the data of temperature protect		
	set the protect temperature	ENTER	save and change		
	No vice menu	diSP: display	ENTER	reverse the display	
		set to show reverse display			
	No vice menu	rEst: reset	ENTER	enter the interface of key	the password is "UP DOWN UP DOWN"
		return Initial State			

3. If need to keep synchronization for long time, there are two ways to do so:
 A. Using the controller to edit program make the strobe, auto run effect, then they must be synchronization.

B. Using the Maser/Slave model

2. Channel data

2.1 Standard channel model

Channel	Data	Function	Mark
CH1	0~255	Main Dimmer	
CH2	0~255	Color 1 dimmer	
CH3	0~255	Color 2 dimmer	
CH4	0~10	No strobe	this channel control the speed when running the build-in program
	11~255	Speed of strobe from slow to fast	
CH5	0~20	Speed of dimmer 2 (the slowest and softest)	
	21~40	Speed of dimmer 2	
	41~60	Speed of dimmer 1	
	61~80	Speed of dimmer off (fastest and no any delay)	
	81~99	Inner program 1	
	Each 10 data is a program	
	190~199	Inner program 10	
	200~240	Change color by sound control	
241~255	Strobe by sound control		

2.2 Basic channel model

Channel	Data	Function
CH1	0~255	Color 1 dimmer
CH1	0~255	Color 2 dimmer

3. Operation

3.1. Key operation

A.00 1 (1~512)

d.00 1 (1~512)

StAt → **r.255** (0~255)

→ **St.00** (0~20)

EENP → **0**

→ **E.080** (40~120)

d,SP

rEst

Menu :

The first list is the main menu (press MENU to exchange), the second list is submenu (press ENTER to get in or exchange)

If the menu include the decimal point, that's the data, and it can be set by the Key of Up/Down.

Key operation :

Key of "MENU" (Press it and can save the data)

If it's the main menu, it will exchange to next main menu.

If it's the submenu , it will back to main menu.

Key of "ENTER" (Press it and can save the data)

If it's the main menu and it have submenu, it will enter the submenu.

If it's the submenu, it will exchange to the next submenu

Key of "UP/DOWN"

It's no function if the menu not include the decimal point.

If the menu include the decimal point, it can set the data after the decimal point. And it need to press "ENTER" to save the data.

3.2. Menu Data

Menu		State	Operation		Remark
Main Menu	Vice Menu				
A.00 1	No vice menu	A: advance	UP/DOWN	adjust ID address	disconnect the controller and connect the master light, then it will follow the master light. It will flicker if no signal.
		External control mode (standard channel model)	ENTER	save the ID address	
d.00 1	No vice menu	d: dmx	UP/DOWN	adjust ID address	It will flicker if no signal.
		External control mode (Basic channel model)	ENTER	Save the ID address	
StAt	two vice menu	StAt: static	ENTER	enter vice menu	
		Static model			
	r.255	C: Color	UP/DOWN	change value of color	
		Set the color	ENTER	save the data change to the vice menu	
	St.00	St: strobe	UP/DOWN	change value of strobe	
		strobe and its speed	ENTER	save and exchange	